



DATA SHEET

SCENE PLATE REMOTE



The **ecoLUX** 'Hand held Scene Plate' remote performs the functions of a scene set control plate. This is used with our plug in and hardwired control modules to control different lighting groups at different levels as well as some other non-lighting functions, such as electric blinds.

Working with any scene set control plate, the seven buttons on this remote mimic the buttons on the scene set control plate. Using the remote you can call Scenes 1 - 4, Raise, Lower, and Off. The Off button can also be programmed to a scene value. By pressing and holding buttons 1 - 4 you call scenes 5 - 8.

The remote requires no commissioning, but it requires a programmed scene set control plate to work with.

IMPORTANT: The information contained in this data sheet is subject to change at any time without notice

Lighting Controls Ltd., 5 Bourne Mill Business Park, Guildford Road, Farnham, Surrey, GU9 9PS, U.K.

Tel: +44 (0)1252 470027 Fax: +44 (0)1252 782288 email: info@lightingcontrols.ltd.uk web: lightingcontrols.ltd.uk